

FIRST USE

Please follow this procedure to adjust battery capacity level:

- 1) Fully charge batteries until charger will stop.
- 2) go into display settings by touching and holding the center of the display for 5 sec. new tab will open.
- 3) on new tab (Display setup view) choose Battery icon, new tab will open.
- 4) on new tab (battery details view) choose number Ah Icon (eg. 220Ah) and on new tab adjust the battery capacity to match the capacity on the battery pack label. If current capacity match your battery capacity change capacity to any number and then change it back to your battery capacity - this will reset the battery level shown on the display to 100%.

Please follow this procedure to adjust battery voltage:

- 1) fully charge batteries until charger will stop.
- 2) measure voltage on batteries using voltmeter.
- 2) go into display settings by touching and holding the center of the display for 5 sec. new tab will open.
- 3) on new tab (Display setup view) choose slide switch icon (bottom left icon), new tab will open.
- 4) on new tab (battery details - shunt calibration) adjust the voltage by changing the lowest parameter (third) accordingly to your measured voltage.